The Weather Channel™

EZ Crank™
Radio Extreme

User's Manual

www.ExcaliburElectronics.com Model No.: H632S-WC

Congratulations on your purchase of The Weather Channel® EZ Crank™ Radio Extreme from Excalibur Electronics, Inc. This is a perfect accessory to have in your backpack, car, boat or home.

Please read through this manual thoroughly especially noting safety and care instruction. Keep this manual for reference. This package contains 1 EZ Crank Radio Extreme, 1 headphone set and 1 User's Manual.

Features

The Weather Channel® EZ Crank Radio Extreme features a powerful flashlight and radio designed around our EZ Crank technology in a comfortable, ergonomic housing.

- Rechargeable batteries
- Super-bright LED is visible for over a mile.
- Headphone jack

How To Use

Powering the Radio Extreme

The Weather Channel® EZ Crank Radio Extreme is powered by a hand-powered EZ Crank. Turning the EZ Crank will provide the unit with power for the flashlight and radio.

When winding the crank to power the Radio Extreme remember to turn the unit off first.

When powering the unit for the first time or after a long time of non-use, it is recommended that you turn the EZ Crank for three to five minutes.

EZ Crank Radio Extreme will provide thirty minutes of light and radio power from one minute of turning. If the unit is completely drained of power we recommend winding it for three to five minutes to achieve optimal perfomance.



Note: While winding, an indicator light on the unit will illuminate.

Using the Radio Extreme

The Radio Extreme uses LEDs to provide bright, powerful light while consuming less power than a regular flashlight.

To use the flashlight simply press the Light On/Off button located near the headphone jack.

Listening to FM Radio

Turn the unit on by sliding the VOL wheel. Slide from left to right to turn the unit on.

Scan

- Use this button to search for radio frequencies.

Reset

- Use this button to return to the lowest radio frequency.

Safety and Care

- Always turn off the flashlight and radio when charging.
- Avoid rough handling such as bumping or dropping.
- Avoid extreme temperatures. For best results, use between the temperatures of 39º F and 100º F (4º C and 38º C).
- Clean using a slightly damp cloth. Do not use cleaners with chemical agents.
- Do not expose the Radio Extreme to direct sunlight or other heat source for any length of time.
- Clean the lense with glass-cleaning products.
- Do not use petroleum distillates (such as gasoline or kerosene) or solvents (such as acetone) to clean any part of the Radio Extreme.

Special Warning

EZ Crank Radio generates a strong magnetic field that surrounds it. Keep the unit at least one foot away from medical devices, computers, magnetic storage media, or other devices such as:

- Pacemakers
- Credit cards
- Video and cassette tapes
- Televisions
- Computer discs
- Any device with a cathode ray tube (CRT)

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable I interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Excalibur Electronics reserves the right to make technical changes without notice in the interest of progress.

90-DAY LIMITED WARRANTY

EXCALIBUR ELECTRONICS, INC., warrants to the original consumer that its products are free from any electrical or mechanical defects for a period of 90 DAYS from the date of purchase. If any such defect is discovered within the warranty period, EXCALIBUR ELECTRONICS, INC., will repair or replace the unit free of charge upon receipt of the unit, shipped postage prepaid and insured to the factory address shown below.

The warranty covers normal consumer use and does not cover damage that occurs in shipment or failure that results from alterations, accident, misuse, abuse, neglect, wear and tear, inadequate maintenance, commercial use, or unreasonable use of the unit. Removal of the top panel voids all warranties. This warranty does not cover cost of repairs made or attempted outside of the factory.

Any applicable implied warranties, including warranties of merchantability and fitness, are hereby limited to 90 DAYS from the date of purchase. Consequential or incidental damages resulting from a breach of any applicable express or implied warranties are hereby excluded. Some states do not allow limitations on the duration of LIMITED 90-DAY WARRANTY and do not allow exclusion of incidental damages, so the above limitations and exclusions in these instances may not apply. The only authorized service center in the United States is:

Excalibur Electronics, Inc.
13755 SW 119th Ave
Miami, Florida 33186 U.S.A.
Phone: 305.477.8080
Fax: 305.477.9516
www.ExcaliburElectronics.com

Ship the unit carefully packed, preferably in the original carton, and send it prepaid, and adequately insured. Include a letter, detailing the complaint and including your daytime telephone number, inside the shipping carton. If your warranty has expired and you want an estimated fee for service, write to the above address, specifying the model and the problem.

NOTE: Please do not send your unit without first receiving an estimate for servicing from EXCALIBUR ELECTRONICS, INC. Contact us before sending your unit. We cannot store your unit!

Excalibur Electronics, Inc.
13755 SW 119th Avenue
Miami, Florida 33186

Phone: 305.477.8080
Fax: 305.477.9516

Visit Us At:
www.ExcaliburElectronics.com

H632S-WC TWCEZCranRadExt 031907 v3